

PARTS LIST

FOR

HARDINGE SUPER-PRECISION TOOL ROOM LATHE

MODEL HLV-H

STARTING SERIAL #100

HOW TO ORDER REPAIR PARTS

You Will Receive Quicker And Better Service When Ordering Repair Parts If You Will Follow The Instructions Below


These Four Requirements Are Essential:

- 1. State Amount Required.
- 2. Give Key Number, Part Number and Name of Part.
- 3. Give Complete Serial Number of the Machine. (This is Located on the Back of the Bed at the Right Hand End.)
- 4. Specify How and Where to Ship.

TABLE OF CONTENTS

Bed Assembly
Brake Assembly
Carriage Apron Assembly
Carriage and Cross Slide Assembly
Carriage Half Nut Assembly
Clutch Assembly
Collet Closer Assembly
Coolant Facilities
Contour Tracing Assembly View I
Electric Control Panel
Four Station Turret
Gear Assembly
Gear Box Units Change Gear Bucket Cluster Shaft and Change Shaft Clutch Shaft and Intermediate Shaft Gear Box Gear Box Idler Shaft and Reverse Shaft Gear Box Tumbler and Shaft Page 47 Page 41 Page 45
Headstock Assembly
Micrometer Stop
Pedestal Base Assembly
Power Feed Control Box
Power Feed Assembly
Radius Turning Attachment
Rear Tool Holder Slide Assembly
Square Turret Assembly
Tailstock Assembly
Taper Attachment
Tool Post Assembly
Variable Speed Actuator Assembly
Variable Speed Control Box Assembly
Variable Speed Pulley Assembly

	ART MBER	cs.	PART NAME	KEY	PART NUMBER	PCS.	PART NAME
1 IH-10 2 IH-11 3 79-83 4 IH-27 6 R-698 7 IH-35 8 FB-69 9 10082 10 VD-47 11 50-10 12 55-100 14 55101 15 IH-99 17 18 IH-11 20 181-8 21 IH-14	033 51 24 9 9 58 23 24 9 225 225 2229 223 4 238 2063	11111231 11111211 11	Micro Switch Name Plate Seal Spring Plunger Spindle Lock Pin Screw Lock Screw Dowel Screw Collet Closer Bracket Conduit Connector Conduit Lock Plug Screw Screw Locking Plug Seal Screw Insulating Sleeve Micro Switch Insulator Snap Ring Handwheel Key	37 38 39	HLD-6284 7L-9862-10 HL-4160 VSG-9625 LH-4053 HC-265 LH-263 LH-4057 100828 LH-6424 LH-275 LH-282 CW-6407 101328 HL-10053 300106 LH-256 T10-8979 HCA-4068 HLA-9980 7-9852 7A-316	1 1 2 1 1 pr. 1 1 6 1 1 1 1 4 4 4 1 1 1 1 1 1	Spindle Gear Spring Pin Cork Head Belt Spindle Pulley Bearing Frame Assembly Spacer Screw Gasket Front Cap Spindle Assembly Splash Guard Screw Lockwasher Screw Name Plate Pulley Key Clamp Nut Spacer Wave Washer Handwheel




HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

TAILSTOCK ASSEMBLY PARTS LIST

PART NAME	Tailstock Body Locking Plug Clamp Bolt Spacer Handle Washer Screw Handle Shim Lock Screw Spindle Key Binding Nut
PCS.	ненененененененененененененененененене
PART NUMBER	IH-401 6-9094 HL-8298 HL-10028 HL-418 6-9244 100308 IH-1552 TL-6815 IH-11006 IH-1554
KEY	25 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5
PART NAME	Screw Zero Ring Woodruff Key Handle Stop Pin Stop Pin Lock Nut Feed Screw Nut Screw Tailstock Spindle Tailstock Genter Screw Gib
PCS.	
PART NUMBER	550506 I.H-407 3-1759 CD-4638 CP-4630 VD-1950 I.H-402 590504 I.H-405 I.H-9480 I.H-9480
KEY	23 55 55 55 55 55 55 55 55 55 55 55 55 55
PART NAME	Feed Screw Bearing End Cap Screw Dial & Support Assembly Spring Washer Mut Handwheel Assem. Plug
PCS.	
PART NUMBER	IH-403 CP-4140 IH-11005 100320 HIE-10335-1 HI-8759 R-7859 IH-2068 CW-9052 IH-410 6W-9450
KEY	100870 0150870


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED.



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

COLLET CLOSER ASSEMBLY PARTS LIST


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED.



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.


PART NAME	Lead Screw Bracket Shim Name Plate Washer Washer Spring Nut Spacer Brass Plug Screw Collar Nut Plunger Nut Plunger Bed Plug Escutcheon Pin Low-Stop-High Plate
PCS.	H HMMMM QQQHHHHHHQH
PART NUMBER	IH-9993 IH-9995 FB-256 2-8266 5P-6433 IN-6253 SN-4626 S6A-8265 9896 37-292 550505 TL-6344 U-4141 IH-6287-L IH-6287-L IH-6287-L IH-6287-L IH-6287-L IH-6297 R-331 FB-1669
ΚĒΥ	008400100001000000000000000000000000000
PART NAME	Plug Bushing Bearing Nut Nut Taper Pin Dowel Stop Rod Lead Screw Escutcheon Pin Name Plate Collar Taper Pin Screw Lockwasher Dowel Bearing
PCS.	
PART NUMBER	CP-9360-2 HL-9544 HL-9545 HL-9543 HL-9543 HL-9991 100312 HL-6324 HL-6324 HL-6324 HL-6324 HL-256 HL-9991 HL-9994 HL-9994 HL-9994 HL-9994
KEY	23 83 3 3 3 3 3 3 3 3 5 5 5 5 5 5 5 5 5 5
PART NAME	Knob Speed Lever Assem Reverse Lever Assembly Snap Ring Block Pivot Wut Spring Washer Wut Screw Iever Arm Handle Plunger Screw Lock Screw Spring Screw Fin
PCS.	011 00114000111101111111111111111111111
PART NUMBER	MD-3285 LH-3721 LH-3721 LH-3720 31-8231-2 LH-1052 LH-1052 LH-1052 LH-6945 U-4141 TL-6945 RAA-6239 TA-6357 TP-3792 551210 TL-4923 550308 LH-8627
KEY	10 m 4 m 0 m 0 0 1 1 2 2 2 2 2 6 0 0 0 0 0 1 1 2 2 2 2 2 0 0 0 0 0 0 0 0

WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TALLSTOCK END OF THE BED.




HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

KEY	PART NUMBER	PCS.	PART NAME	KEY	PART NUMBER	PCS.	PART NAME
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 21 22 23 24 25	LH-11028 LH-11027 LH-6303 LH-328 150910 LH-11011 100306 LH-11012 LH-11060 IH-10646-1 OFA-9431 LH-11025 CH-11029-2 LH-10646 LH-11031 HL-10331 LH-11026 300306 LH-11018 5-1467 300316 LH-11029-1 LH-11030 LHA-11029-2 OW-10109	11111142441223141142412	Seal Cover Cover Cross Feed Nut Screw Cross Slide Screw Screw Cross Slide Plug Compression Sleeve Meter Unit "O" Ring Connector Tubing Meter Unit Bushing Dot Plug Junction Block Screw Cover Pipe Plug Screw Tubing Compression Nut Tubing Oil Window	26 28 29 31 31 31 31 31 31 31 31 31 31 31 31 31	HL-9987 HL-6424 CH-11031 LH-6159 HM-6160 550705 HL-10246 LH-407-1 550504 LH-3950 LH-368 300608 HL-10433 LH-326 LH-6991 LH-7909 LH-334 HLE-10335-2 R-331 TA-335 TA-335	1 1 2 1 1 1 1 1 1 1 1 1 1 1	Oiler Gasket Bushing Gib Gib Screw Screw Washer & Screw Assembly Zero Ring Screw Nut Cross Slide Screw Seal Bearing Cross Feed Screw End Cap Bearing Bushing Dial & Support Assembly Nut Crank Lock Screw




HARDINGE BROTHERS, INC., EIMIRA, NEW YORK, U.S.A.


KEY	PART NUMBER	PCS.	PART NAME	KEY	PART NUMBER	PCS.	PART NAME
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 1 22 23	HLE-10335-1A HL-10246 R-331 550705		Bearing Key Block Eccentric Shaft Eccentric Support Hub Wave Washer Screw Handle Ball Screw Zero Ring Bearing Bearing Nut Bushing Dial & Support Assembly Washer & Lock Screw Lock Screw Crank Handle	24 25 26 27 28 29 31 33 33 34 35 37 38 39 44 44 45 47 48	IH-7859 IH-490 570504 IH-4234 TL-414 IHA-6630 100512 HL-9991 IH-325 IHA-357 HM-6160 IH-358 HIA-366 HI-9847 300206 IHA-362 IHA-10423 100506 450105 5-1465 6A-8648 TL-363 N-590512 DSA-328 DSA-1950	2211114211211 2111211211	Plug Spring Screw Stop Screw Nut End Cap Screw Dowel Feed Screw Slide Gib Screw Gib Draw Bolt Shim Spacer Screw Index Slide Wiper Screw Key Pilot Ring Eccentric Stop Screw Nut Lock Nut



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

KEY	PART NUMBER	PCS.	PART NAME	KEY	PART NUMBER	PCS.	PART NAME
1 2 3 4 5 6 7 8 9 1 1 1 2 1 4 1 5 6 7 8 9 1 1 1 2 1 4 1 5 6 7 8 1 9 2 2 2 2 2 2 2 2 2 2 2 3 3 3 3 3 3 3 3	LHA-1990 LHA-10336 B-150612 49A-7984 CM-2845 5P-2843 FPB-4698 LH-11037 650104 VDA-3780 WE-2850 LHB-4910 LH-3288 LH-10565-1 UE-4920 HPC-9858 LH-4911-2 100410 5P-6431 6-8780 6A-2172 TL-4757 MD-3591 B7-1502 300424 BMD-2883 HIA-10073 6-8747 150610 CM-2845 SP-2843 VD-8297 LH-3788 551012 TL-6466 6W-9454 U-6916 300612 49A-7984 CM-2845	11222211 11121111241 16664448000121115222	Base Support Screw Washer Lockwasher Nut Name Plate Belt Replacement Plate Drive Pin Motor Door Pull Rod Link Cork Pad Pull Rod Bed Seal Cotter Pin Brake Plate Cork Pad Screw Washer Collet Board Assembly Collet Board Washer Lockwasher Nut Screw Nut Screw Lockwasher Nut Collet Door Shelf Screw Brass Plug Adjustable Foot Door Bumper Screw Washer Lockwasher	412344567890123456789012345678901234567890123456789012	5P-2843 HL-9997 CM-2885 5-1466 HLA-9999 LH-10000 150716 HLA-9998 150824 MD-3227 BK-10438 DV-10680 HCB-9663 VS-9672 R-7980 VSG-9624 VSA-3177 550605 HL-10006 151036 TP-6836 MD-6826 WA-9191 SS-10032 CMB-2249 HCD-1991 HCB-9663 VS-9672 300608 HL-505 UA-4034 U-3985 3-3606 DV-1995 VD-3782 B-151016 MD-6826 MD-3591 3-1425 DVB-9623 100306 LH-4911-1	22241121222211211414144441111144424214441114	Nut Insulator Bushing Washer Nut Support Plate Support Screw Screw Support Plate Screw Lockwasher Washer Nut Stud Bushing Door Catch Motor Belt Motor Pulley Screw Insulator Bushing Screw Nut Washer Washer Lock Screw Motor Motor Plate Stud Rubber Bushing Screw Washer Nut Lockwasher Washer Hinge Eye Bolt Rear Cover Screw Washer Lockwasher Nut Clamp Screw Cork Pad






HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.


ME	Ring
PART NAME	Nut Pin Brake Link Screw Lockwasher Washer Lockwasher Washer Nut
PCS.	нн наааааа
PART NUMBER	U-3942 9862 9862 5BA-9654 100610 CM-2845 9-7910 X50-8231 150824 MD-3227 BK-10438 DV-10680
KEY	24 28 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8
PART NAME	Gasket Cover Screw Solenoid Solenoid Support Screw Lockwasher Mounting Plate Screw Spacer Washer
PCS.	
PART NUMBER	DVA-10116 DVA-10115 300410 DVD-9820 8831 GEB-10218 100308 CM-2840 DVA-9652 BKA-10493 GEA-10111 BMD-3623
KEY	\$35556666666666666666666666666666666666
PART NAME	Bushing Support Screw Nylon Plug Key Nut Adjusting Bushing Cork Pin Brake Pin Screw Nut Spring
PCS.	
PART NUMBER	BKA-9656 550608 N6W-9450 HC-10259 BMD-2883 HC-10258 FBC-4160 DV-9655 DVA-9653 3-1425 HC-8872
KEY	100870V4551


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED.



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

KEY	PART NUMBER	PCS.	PART NAME	KEY	PART NUMBER	PCS.	PART NAME
1 2 3 4 5 6 7 8 9 10 11 2 13 14 15 16 17 18	TL-6831 HIC-6195 HL-10249 U-10245 HLE-10335-3 137-8231-8 LH-11015 LH-6656 LH-6660 TMB-3977 LH-4144-1 LH-6700 HL-10429 LH-6655 LH-10898 LH-6708 CH-4144-1 LH-10899	111111111111111111111111111111111111111	Handwheel Handle Handwheel Dial Lock Screw Plug Dial & Support Assembly Snap Ring Sleeve Handwheel Bearing Shaft Oilite Bearing Gear Bearing Gear Bearing Seal Rack Gear Cork & Plate Assem Clutch Pin Oilite Bearing Longitudinal Clutch Gear	19 20 21 22 23 24 25 26 27 28 29 31 32 33 34 35 36	IH-6723 IH-11020 CH-4144-1 IH-4746 IH-11024 CP-4145-2 IH-11021 HC-11000 IH-10896 CP-4140 25-8231-2 550504 SS-10031 550608 5-1465 IHA-10494 IHA-10495 IH-4144-2	1111 4 2226111111	Clutch Disc Assem. Intermediate Gear Oilite Bearing Clutch Shaft Assem Cross Feed & Pinion Gear Assembly Needle Bearing Intermediate P. F. Gear Bowed Washer Disc Clutch Bearing Snap Ring Screw Lock Screw Screw Woodruff Key Gear Stud Idler Gear Needle Bearing






HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

	Screw Fin Pin Cover
PART NAME	w. ch Body Scr. leandle w Cup Instruction Plate ttcheon Pin r Screw r iage & Cove
PART	Screw Clutch Body Handle Ball Handle Screw Oil Cup Oil Instruct Plate Escutcheon P Wiper Screw Wiper Screw Viper Carriage & C Screw
	SOUTH MOOD ON THE SOUND TH
PCS	1 F Q Q Q Q H A A A A A A A A A A A A A A A
PART NUMBER	100308 100314 IH-6158 TI-6126 100310 HI-10277 CPA-10011 R-8044 HI-505 300608 HCA-8050 IHA-4831 100620
KEY	33333333333333333333333333333333333333
PART NAME	Handle Ball Handle Wiper Spacer Wiper Spring Cover Screw Dowel Screw Magnetic Draw Plug Interlock Plate
PCS.	1499794949
PART NUMBER	TL-6158 TL-6126 HCA-6076 HCB-10311 100610 R-4853 HL-6687 550316 562-10331 R-4853 100320 LH-10998 LH-9482
KEY	52 53 53 53 53 53 53 53 53 53 53 53 53 53
PART NAME	Left Wiper Wiper Screw Center Wiper Dial Washer & Screw Assembly Gib Screw Right Wiper Lock Bolt Screw Collar Ecentric Instruction Plate
PCS.	
PART NUMBER	I.H-8050-1 I.H-10246 I.H-370 I.H-370 I.H-6684 2V-2302 II.H-9796 II
KEY	10m4 r06p813


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED.



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

PART NAME	Body ing Ring
PART	Stop Screw Clutch Body Plug Screw Spacer Spacer Retaining R Nut
PCS.	000000
PART NUMBER	CP-10674 CPA-6933 CP-9360-4 100314 CP-3643 CP-3643 CP-10672 35-8231-2 CP-10673
KEY	20 20 20 20 20 20 20 20 20 20 20 20 20 2
PART NAME	"O" Ring Cam Handle Ball Handle Pressure Sleeve Sleeve Adjusting Bolt Nut Cover "O" Ring
PCS.	
PART NUMBER	OR-0911 IH-6935 IH-6158 TL-6126 CP-10662 CP-10663 CP-4623 CP-1821 OR-1821
KEY	01 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
PART NAME	Interlock Plunger Spring Interlock Bar Spring Plunger (Long) Plunger (Short) Bearing Nut
PCS.	нннамннам
PART NUMBER	HL-9483 HL-9484 IH-6675 CP-10661 SPA-7872 IH-6998-2 CP-9323 TL-414
ΚĒΥ	この 日 と ら と と と と と と と と と と と と と と と と と

WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED.




HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

POWER FEED ASSEMBLY PARTS LIST

PART NAME	Spacer Motor Bearing Worm Gear Housing Shaft Bearing Seal Lock Screw Key Housing
PCS.	
PART NUMBER	HC-9578 TL-6617 LH-9349 LH-9559 RA-7909 HL-10124 LH-4044 3-1759 LH-7502
ΥĘ	16 17 22 22 22 24 24
PART NAME	Brush Holder Brushes With Springs Brush Cap Grommet Motor Bearing Fnd Bell Motor Armature
PCS.	00 0HHHHH
PART NUMBER	E-9332 D-9332 C-9332 J-9332 F-9332 A-9332 A-9332
ΚĒΥ	8 6 9 1 3 5 1 5
PART NAME	Mut Worm Wheel Retaining Ring Worm Retaining Screw Worm Pin Field Coil, Pole & Shell Assembly
P.Cs.	ннан мнн
PART NUMBER	EN-4624 1.H-9345 87-8231-1 HL-9393 100812 35-9862-8 B-9332
KEY	しらら ちらて


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED.



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

PART NAME	Bracket Terminal Strip Marker Strip Mounting Plate Screw Seal Indicator Plate Screw Connector
PCS.	
PART NUMBER	CF-9568 S4-11170 CF-9175-3 CF-9568-1 CF-11164 450510 HIA-9713 CFA-9510 HL-10794 400608 6-9207
KEY	3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3
PART NAME	Screw Screw Rectifier Assem. Marker Strip Terminal Strip Switch Reactor Screw, Nut & Lockwasher Assembly Marker Strip Screw Housing
PCS.	- M
PART NUMBER	350340 350308 CH-9335-S CF-9175-1 S4-8116 CF-3650 PF-10619 400-307 MD-9028 CF-9175-2 350210 CF-6001
KEY	13 14 14 15 15 15 15 15 15 15 15 15 15 15 15 15
PART NAME	Screw Retaining Ring & Oil Seal Assembly Washer Autotransformer Retaining Pin Shaft Coupling Screw Rheostat Braking Resistor Center Washer, Mica Washer Assem
PCS.	87 MT 87 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8
PART NUMBER	400307 PF-10620 PF-10622 5-1895 CF-1163 100306 CF-10764 PF-10472 6000-10621 6010-10621
KEY	10 m4 n0 t m o l


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED.




HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

回	ng Screw ap Tt Nut n Late .r
PART NAME	usi t t Wor Sha she she
PAR	Key Nut Housi Spring Vertical Nut Lock Nut Bearing C Screw Shim Spacer Motor Wor Motor Wor Motor Wor Motor Wor Insulator Backing F Insulator Bushing Lockwashe Screw
PCS.	
PART NUMBER	VS-10379 DVB-10209 DV-10311 DV-10311 DV-10811 DVB-101087 100308 VSC-6481 VSC-6481 VSC-1799 DV-10422 CP-9342 DV-10422 CP-9342 DV-10428 DV-10538 MV-10538 MD-3591 151020
KEY	\$4.00 82 83 83 83 82 82 82 82 82 82 82 82 82 82 82 82 82
PART NAME	Cover Key Worm Wheel Gasket Bearing Shim Shim Trip Rod Stop Lock Screw Nylon Plug Screw Grease Fitting
PCS.	
PART NUMBER	DVA-10195 5-1465 DVA-10183 DVA-10216 TL-6618 TL-6481 DV-10419 550304 N37-483 DVB-10191 DV-10327
KEY	5449586888 838888
PART NAME	Micro Switch Screw Lockwasher Spring Switch Trip Roll Pin Motor Bearing (Rear) Motor Bearing (Front) Trip Rod Screw Control Housing
PCS.	しれし しし しりのりゃかり
PART NUMBER	DVB-10224 350116 SL-8137 DV-10418 DV-10420 4S-9862-16 TL-617 JVB-10417 300308 DVB-10417 300308 DVB-10417
ΚĒ	10m4rv0r 80 011d

WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED.






HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

VARIABLE SPEED PULLEY ASSEMBLY PARTS LIST


PART NAME	Screw Washer Washer Rubber Washer Hanger Bracket Nut Pivot Screw Lockwasher
PCS.	してたしころっちょう
PART NUMBER	101320 5P-6433 7-1502 QS-10143 DV-10542 LH-1990-47 5-1466 QS-10141 5P-6434
KEY	1 1 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8
PART NAME	Nut Adjusting Screw Rubber Bumper Bushing Insulator Screw Adjusting Screw Bushing
PCS.	コン こ こ い い こ に い た た
PART NUMBER	7-1502 551024 DV-10541 DV-10567 DV-10537 151020 551024 DV-10536
KEY	21454595
PART NAME	Retaining Ring Bearing Shim Drive Support Pulley Assembly Pivot Block Support Bracket Lockwasher Screw
PCS.	40 HHHHVH
PART NUMBER	165-8231-1 CW-9058 510-10405 CHA-10180 DVC-9832 QS-10140 QSA-10121 5P-6434 101316
KEY	1 0 m 4 m 0 r m o

WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED.



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.


KEY	PART NUMBER	PCS.	PART NAME	KEY	PART NUMBER	PCS.	PART NAME
12345678	LH-10181 HL-9553 LH-10189 LH-10188 DV-10185 550606 550608	1 1 1 1 2 2	Control Box Brake Switch Coolant Switch Window Indicator Plate Indicator Tip Lock Screw Screw	90 11 12 13 14 15	LH-10190 550604 550606 75-10229 300306 DV-9973	111262	Support Screw Connector Conduit Screw Control Unit



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.


PART NAME	Lockwasher Connector Legend Plate "Start" Button Gasket Handle Screw Lockwasher "Stop" Button Switch Data Plate Escutcheon Pin Pilot Light Captive Screw Spacer 3/4" Connector - 90°
PCS.	N4444686444488
PART NUMBER	CM-2845 6-9207 1H-10372 1H-9973 CQA-9976 JG-10359 350304 WD-9028 JG-10359 350304 WD-9972 IHC-8972 GD-10465 GD-10465 GD-10755
KEY	00000000000000000000000000000000000000
PART NAME	Cam Speed Switch Screw Screw Lockwasher Nut Relay Screw Fluse Pilot Light Lamp Relay Support Heaters Relay Screw Contactor Panel Plate Screw Contactor Grounding Post Marker Strip Magnetic Contactor Grounding Post Nut for Post Screw Lockwasher Fuse Transformer Screw
PCS.	しょしなない しょししょう くりしょうしょう くしし ちょうしょうしょうしょう しょうしょうしょうしょうしょうしょうしょう しょうしょうしょう しょうしょう しょう
PART NUMBER	DVB-2835 360307 150610 CM-2845 5P-2843 JHL-10019 350206 JWL-9610 DQR-10557 LH-9864 9833 HVA-8122 360307 VD-10230 LHA-1904 350310 H15-8116 H15-8775 DV-10546 350206 HC-2840 JHC-9610 JHC-9610 JHC-9610
KEY	2724644444444333333333333333333333333333
PART NAME	Fuse Cut Out Terminal Bracket Marker Strip Screw Nut Lockwasher Contactor Screw Marker Strip Terminal Strip Screw Main Line Fuses Fuse Clips (1set) Disconnect Switch Screw Cable Clamp Screw Cable Clamp Screw Cable Clamp Screw Cable Clamp Screw Cable Assembly Screw Lockwasher Lockwasher
PCS.	ストーサー とししとししていいしょしないしょしょし
PART NUMBER	DV-10017 LH-11061 A-9175-4 360307 4-8116 350312 37A-361 CM-2840 RG-8775 350318 HL-9175-5 H5-8116 350310 SD-9610-1 JG-10017 JG-10016 350307 DVB-9623 100306 50-10225-90 LH-7220 350104 350508 6-9181
KEY	00000000000000000000000000000000000000


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

KEY	PART NUMBER	PCS.	PART NAME	KEY	PART NUMBER	PCS.	PART NAME
12345678	PART NUMBER TL-6126 TL-6158 TL-6157 MD-3253 TL-6695 37-483 LH-11017 OR-2327	PCS.	Ball Handle Half Nut Handle Handle Hub Taper Pin Washer Brass Plug Gib Screw "O" Ring	9 10 11 12 13 14 15 16	PART NUMBER LH-6172 LH-6673 LH-11017-1 550512 CM-2843 TL-6475 R-4853	PCS.	Gib Lead Screw Nut Cam Gib Screw Gib Screw Nut Stop Dowel







HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

	ti O
PART NAME	Spring Plunger Bearing Spacer Gear Guard Plate Iscutcheon Pin Handle Three Change Thread Feed Plate Escutcheon Pin
PCS.	たしし しゃかししょうし
PART NUMBER	6242 6241 6250 6233 6250 6331 8044 8044 8044
KEY	80000000000000000000000000000000000000
PART NAME	Shifter Fork Cover Plate Retaining Ring Pinion Shaft Bushing Plunger Spring Screw Catch Strike Catch Nut
PCS.	
PART	HIA-6245 LH-11013 75-8231-2 HIA-6283-L HIB-9524 TL-6851 6495 550507 350106 6126 9620
KEY	27 27 28 27 28 27 28 27 28 28 28 28 28 28 28 28 28 28 28 28 28
PART NAME	Tumbler Guide Dowel Screw Pinion Shaft Dowel Screw Cover Screw Hinge Screw
PCS.	
PART NUMBER	HIA-9498 TI-6770 100208 HIA-6283-L HI-9530 101014 TI-6608 100406 HIA-9635 HM-9373 45006
KEY	100450000112pp


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED.






HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.


KEY	PART NUMBER	PCS.	PART NAME	KEY	PART NUMBER	PCS.	PART NAME
123 45	TL-6256 TL-6255 TL-6253 HL-6606 101036	PCS.	Gear Bushing Bushing (Single) Single Gear Clamping Bolt Bracket Screw	6 7 8 9 10	TL-6251 TL-6254 TL-6248 TL-6249 TL-6252	PCS.	Clamping Nuts Bushing (Double) Bushing Spacer Clamping Bolt



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.


KEY	PART NUMBER	PCS.	PART NAME	KEY	PART NUMBER	PCS.	PART NAME
1 2 3 4 5 6	TL-6617 IH-11036 IH-9488 IH-11035 100310 IH-9487	2 1 1 2 1	Ball Bearing Knockout Pin 71 Tooth Gear Stop Block Screw Idler Shaft	7 8 9 10 11 12	IH-1465 118-8231-1 N-550506 118-8231-1 HIA-9489 TL-6617	1 2 1 2 1 2	Key Retaining Ring Set Screw Retaining Ring Reverse Shaft Ball Bearing






HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.


KEY	PART NUMBER	PCS.	PART NAME	KEY	PART NUMBER	PCS.	PART NAME
1 2 3 4 5 6 7 8 9 10 11	TI-6617 TA-6216 TI-6616 TI-6270 HIB-6281 HI-9950 HIB-6200 2V-6504 TI-6317 TI-6272 HIB-6296	2111 11111	Ball Bearing Shaft Bushing Ball Bearing Quick Reverse Clutch Forward Gear Assem Forward Nut Shaft Ball Bearing Key Clutch Bushing Reverse Gear Assem	12 13 14 15 16 17 18 19 20 21 22 24	HL-9949 118-8231-1 TL-6617 TL-6356 HL-6201 TL-6318 HLA-6211 CD-4629 TL-6219 HL-6212 HLA-6210 HLA-6221 118-8231	1221112112	Nut Retaining Ring Ball Bearing Key Shaft Key 33 Tooth Gear Dowel Pin Bushing 50 Tooth Gear 22 Tooth Gear Retaining Ring






HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.


KEY	PART NUMBER	PCS.	PART NAME	KEY	PART NUMBER	PCS.	PART NAME
1 2 3 4 5 6 7 8 9 10 11 2 13 14 15 16 17 18	TL-6278 TL-6618 50-8231-2 HIA-6214 CD-4629 HL-6215 TL-6744 TL-6617 118-8231-1 HL-6745 HIA-6213 TL-6276 TA-6231 HIA-6747 TL-6482 TL-6480 137-8231-1 TL-6278	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Key Ball Bearing Retaining Ring 44 Tooth Gear Dowel Shaft Key Ball Bearing Retaining Ring 48 Tooth Gear Key Key 22 Tooth Gear .005 Shim .001 Shim Retaining Ring Key	19012345678901233456 222222233333333	HL-6226 TL-6621 TL-6319 HIA-6204 HIA-6204 HIA-6206 HIA-6208 HI-9491 HI-6282 HIA-6207 HIA-6205 HIA-6205 HIA-6224 HI-9495 TL-6233 TL-6280	1111111111111111	Collar Bearing Key 23 Tooth Gear 26 Tooth Gear 32 Tooth Gear 40 Tooth Gear Spacer Bearing Cluster Shaft 54 Tooth Gear 28 Tooth Gear 24 Tooth Gear 10ck Nut Spacer Gear Screw





HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

KEY	PART NUMBER	PCS.	PART NAME	KEY	PART NUMBER	PCS.	PART NAME
12 3456	HL-9490 HIC-6767 450105 HL-10442 118-8231-1 HL-6232	1 1 2 2 2 1	Interlock Shaft Tumbler Shaft & Gear Bearing Screw Bearing Retaining Ring Shaft	7 8 9 10 11 12 13	RA-7909 HIA-6268 HL-6225 550303 HIB-6228 TA-6231 TL-6617	21112	Idler Bearing Tumbler Body 40 Tooth Idler Gear Screw 20 Tooth Gear Key Bearing




HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

COOLANT FACILITIES PARTS LIST

PART NAME	Lockwasher Gasket Hose Connection Sump Cover Screw Plug Sump Screen Hose Clamp Close Nipple Elbow Pipe Nipple
PCS.	サンファン・ファット サーフ・マー・ファット サーフ・マー・ファット カー・ファット ファット・ファット ファット・ファット・ファット・ファット・ファット・ファット・ファット・ファット・
PART NUMBER	CM-2845 RA-8226 R-8384 VD-8686 300608 MD-3487 LH-8221 LH-8221 LH-8221 LH-8221 LH-8221 LH-966
KEY	28 33 33 33 33 33 33 33 33 33 33 33 33 33
PART NAME	Valve Body Valve Insert Valve Lever Washer "O" Ring Oil Nozzle Spring Washer Screw Conduit Connector Pump Screw
PCS.	
PART NUMBER	OFA-9467 OF-10059 OF-10060 OF-10061 OFB-9431 OFB-9468 OF-10058 CP-1067 350304 50-10225 LH-3325 LH-3325
KEY	100 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
PART NAME	Brass Plug Thumb Screw Upright Brass Plug Thumb Screw Hose Clamp Elbow Support Slide Connector Thumb Screw Brass Plug
PCS.	
PART NUMBER	6W-9450 OR-9471 HL-9926 U-4901 OR-9471 40-6965 UA-6965 UA-9929 OF-10412 OF-10412 OF-10412 OF-10412 OF-10412
KEY	10m4r0cm011du


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TALLSTOCK END OF THE BED



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

PART NAME	Nut Lower Feed Screw End Cap Screw Nut Pipe Plug Swivel Base Lever Ball Screw Dowel Dowel Dowel Dowel Dowel Dowel Dowel Dowel Dowel Took Plug Screw Pin Base Bottom Slide Screw Tool Holder Body
PCS.	
PART NUMBER	DSA-1950 DSA-325 DSB-343 300610 RT-402 5-4167 RTA-9106 RTA-9119 100714 RT-9119 100714 RT-9119 100714 RT-9119 100714 RT-91107 100714 RT-9111 R-615 CD-4629 ILA-9107 100844 RTB-9101
KEY	0000000 000000000000000000000000000000
PART NAME	Bearing Feed Screw Spindle Screw Fivot Post Bearing Nut Upper Bearing Screw Lower Sealing Ring Nut Upper Link Link Link Link Gib Screw Bracket Plunger Gib Screw Screw Screw Screw Screw Screw Feed Screw Nut
PCS.	# # # # # # # # # # # # # # # # # # #
PART NUMBER	LH-7909 RTB-407 RTA-9103 RTA-9105 560605 RTA-9108 RT-9227 100610 RT-1064 RT-7852 DS-8291 DSU-8293 DS-8291 DSU-8293 DS-8291 DSU-8292 DS-8291 DSU-8293 DS-8291 DSU-8292 DS-8291 DSU-8293 DS-8291 DSU-8293 DS-8291 DSU-8292 DS-8291 DSU-8293 DS-8292 DS-8292 DS-8292 DS-8292 DS-8292 DS-8292 DS-8292 DS-8292
KEY	\$4,000,000,000,000,000,000,000,000,000,0
PART NAME	Screw Nut Handle Khob Screw Locking Plug Gib Expansion Plug Screw Screw Bushing Safety Latch Handle Lock Screw Nut Washer & Screw Assembly Dial & Support Assembly Bushing Zero Ring Screw Screw Screw Screw Screw
PCS.	<u> </u>
PART NUMBER	300508 CM-2843 DS-6158 DS-6126 550807 RT-9114 RB-370 DS-9193 N-590512 300306 DS-10509 RT-9104 RT-9104 RT-9104 RT-9103 HLE-10335-1 LH-334 LH-334 LH-334 SF0504 350305 R-7893
KEY	22 23 24 24 24 25 25 25 25 25 25 25 25 25 25 25 25 25


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

	
PART NAME	Knob Index Lock Shaft Bearing Woodruff Key Index Lock Spacer Nut Turret Body Plug Screw
PCS.	
PART NUMBER	TL-6126 LH-7219 LH-7219 LH-7221 LH-8999 LH-9050 LHA-7201 N37-483 550304
KEY	333084 330084 330084 30086 30084 30084 30084 30084 30084 30084 30084 30084 30084 30084 300
PART NAME	Index Screw Ring Screw Adjusting Plate Adjusting Screw Shield Screw Spring 3/8" Diameter Ball Plunger
PCS.	4 4 0 4 4 0 0 0 0 0 0 H
PART NUMBER	LH-7204 LH-9916 100812 LHA-11053 LH-1083-1 LHA-9745 550804 LH-7335 CM-8101 LH-6058 LH-7208
ΚĒ	251 174 174 174 174 174 174 174 174 174 17
PART NAME	Handle Base Screw Screw "0" Ring Clamp Nut Knob Screw Roller Bearing Screw Lock Plug
P.C.S.	
PART	LH-6158 LHA-7202 550505 550506 OR-4043 LHA-4068 LH-1062 LH-1083 LHA-8353 LH-8081
ΚΕΥ	10045001


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

PART NAME	Brass Plug Screw Dial Indicator Contact Point Clamping Screw
PCS.	нана
PART NUMBER	HL-4901 550403 HL-10037 HL-10038 HIA-10039
KEY	65155 65155
PART NAME	Micrometer Head Brass Plug Screw Bushing
PCS.	н н н
PART NUMBER	HL-10040 HL-4901 550304 HLB-10036
KEY	~ ~~~~
PART NAME	Stop Body Screw Washer Bracket
PCS.	
PART NUMBER	I.H. 10034 300412 BMD-3623 I.H. 10035
KEY	H N M A


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TAILSTOCK END OF THE BED



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

PART NAME	Washer Draw Bolt Bracket Nut Dowel Washer Swivel Stud Brass Plug
	Washer Draw Bo Brackel Nut Dowel Washer Swivel Brass
PCS.	QQH MQHHH
PART NUMBER	37-641 HL-6341 137A-361 37A-361 TL-6469 TL-6298
KEY	11. 11. 12. 13. 13. 14. 15. 15. 16. 17. 18. 18. 19. 19. 19. 19. 19. 19. 19. 19. 19. 19
PART NAME	Screw Push Screw Washer Screw Gib Shoe Nut
PCS.	ааннча
PART NUMBER	100306 I.H-1048 TA-6345 150928 TI-6472 TA-6462 TI-6470
KEY	8001757
PART NAME	Screw Lock Bolt Screw Slide Pin Indicator Shim
PCS.	
PART NUMBER	550710 IH-6827 550310 IH-6463 IH-11014 IH-6481
KEY	1 a m 4 h v o r


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE SERIAL NUMBER WHICH IS STAMPED ON TALLSTOCK END OF THE BED



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

PART NAME	Binding Nut Screw Holder Screw Template Holder Screw
PCS.	ннн нню
PART NUMBER	PTA-635 100820 PT-9120 550305 PT-11217 550306
ΚĒΥ	13 14 15 16 18
PART NAME	Locking Plug Bed Adapter Tool Post Handle Washer Hold Down Bolt Block
PCS.	ddddd
PART NUMBER	DT-9094 PT-10547 DS-347 37-641 PT-461 PTA-463
KEY	78 60 1 1 N
PART NAME	Brass Plug Screw Body Nut Extension Shaft Locking Screw
PCS.	нннн
PART NUMBER	37-483 550305 PT-8347 5-1466 PT-9663 6-9095
KEY	りられるって


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER, PART NAME AND MODEL NUMBER OF TRACING ATTACHMENT



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

Part Name		
PART PART NAME KEY NUMBER PCS PCS	PART NAME	Rin Tras Ballide Pin
PART PCS PART NAME KEY NUMBER PCS PART NAME KEY NUMBER PCS PART NAME KEY NUMBER PCS PART NAME RFT-8050-2 Wiper 16 PT-1976 Support Block 33 PC-1045 PCS	PCS.	
PART PCS PART NAME KEY NUMBER PCS PART NAME PCS PART NAME PCS PART NAME PCS	PART NUMBER	570304 550308 6A-8648 450105 N-560306 PT-8321-1 100314 PT-8321-1 CT-6058 PT-7258 R-4853 LH-6126 PT-357
PART PCS PART NAME KEY NUMBER PCS PART NAME PCS	ΑĒΥ	00100000000000000000000000000000000000
PART NUMBER PCS. PART NAME KEY NUMBER FT-8050-2 1 Wiper 16 FT-1376 IH-10465 12 Screw 17 FT-1376 IM-10350 6 Screw 18 F70506 FT-11354 4 Ball Retainer 19 F70506 300206 4 Screw 19 F70506 FT-340 1 Wiper 20 U-2304 FT-340 1 Bid Cap 22 FM-6160 FT-340 1 Bid Cap 22 FM-6160 FT-340 1 Screw 24 F7040 FT-340 1 Screw 26 U-4650 100314 4 Screw 26 U-4650 100314 4 Screw 1 FT-24 FT-833 1 FT-1355 IT-345 FT-1355 1 FT-362 FT-1338 1 FT-362 FT-34 FT	PART NAME	n ng
PART NUMBER PCS. PART NAME KEY NUMBER FT-8050-2 1 Wiper 16 FT-1376 IM-10465 12 Screw 17 FT-1376 IM-10350 4 Ball Retainer 19 570506 Screw 20 U-2304 FT-1358 FT-8050-1 1 Wiper 20 U-2304 FT-340 1 Bad Cap 22 FM-6160 FT-340 1 Screw 25 U-4650 100314 4 Screw 26 U-4650 100314 4 Screw 26 FT-249 FT-833 1 Template 30 FT-345 FT-1355 1 FT-362 FT-362 FT-338 1 FT-362	PCS.	н напапапапапапапапапапапапапапапапапапа
PART NUMBER PCS. PART NAME PU-8050-2 1 Wiper IH-10465 12 Screw 100320 4 Ball Retainer 300206 4 Screw PT-11354 4 Ball Retainer 300206 4 Screw PT-8050-1 1 Wiper 5A-1977 2 Dowel PT-340 1 End Cap 100312 4 Screw PT-1356 1 Stylus 100314 4 Screw CD-4630 2 Dowel Pin PT-8313 1 Top for Swivel PT-1355 1 Template PT-1338 1 Template PT-1338 1 Template		PT-1976 PT-1368 570506 570508 U-2304 PT-8050 HM-6160 PT-279 37-490 LH-345 PT-345 PT-362
PART PCS. NUMBER PCS. PT-8050-2 1 LH-10465 12 100320 6 PT-11354 4 300206 PT-11354 4 300206 PT-1354 4 100312 4 PT-8050-1 2 PT-8050-1 1 PT-1355 1 PT-1355 1 PT-1358 1	KEY	116 23 33 33 31 33 31 31 32 31 32 33 34 35 36 37
PART NUMBER PT-8050-2 LH-10465 100320 PT-11354 300206 PT-8050-1 5A-1977 PT-340 100314 CD-4630 PT-8313 PT-1358 PT-1338	PART NAME	Wiper Screw Ball Retainer Screw Wiper Dowel End Cap Screw Stylus Screw Top for Swivel Twplate Screw for Template
HATTH O'H THATTO HA	PCS.	ト マンマヤンカンシャイカンでして
	PART NUMBER	PT-8050-2 1M-10465 100320 PT-11354 300206 PT-8050-1 5A-1977 PT-8312 PT-1338 PT-1338
₹ 1 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	KEY	7

WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER, PART NAME AND MODEL NUMBER OF TRACING ATTACHMENT




HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

REAR TOOL HOLDER SLIDE PARTS LIST

PART NAME	Screw Bushing Dial Assembly Nylon Plug Dial Lock & Washer Nut Handle Lock Screw
	Screw Bushing Dial Assem Nylon Plug Dial Lock Nut Handle Lock Screw
PCS.	
PART NUMBER	550306 LH-334-1 LH-10335 U-10245 69-10246 R-331 RT-9104 RTA-9113
KEY	11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
PART NAME	Screw Base Draw Bolt Feed Screw Bearing End Cap Zero Ring
PCS.	4 H Q H H H H
PART NUMBER	100616 1H-463 37-465 1H-9103 1H-4144 1H-343 1H-407-2
KEY	8 6 5 1 4 5 4
PART NAME	Gib Screw Tool Holder Slide Tool Holder Base Set Screw Screw Lock Bolt
PCS.	н и н н м и и
PART NUMBER	IH-453 100308 IH-9106 IH-455 N550306 100308 IH-466
ΚĒΥ	1 0 m t m 0 ト


WHEN ORDERING PARTS, GIVE KEY NUMBER, PART NUMBER AND PART NAME. BE SURE TO GIVE COMPLETE MODEL NUMBER WHICH IS STAMPED ON TOOL HOLDER SLIDE



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

Cover Knob Handle Ring Screw Turret Body Spring Plunger
T T T T T T T T T T T T T T T T T T T
AT-10413 TL-6126 LH-6158 AT-9745 550508 AT-7201 HCT-7335 AT-345
192 102 103 103 103 103 103 103 103 103 103 103
Screw Handle Support Face Cam Brass Plug Screw Washer Nut
дааааа
550506 AT-11250 AT-10312 47-483 550306 MD-3248 5P-1957
8 6 5 1 5 5 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
Draw Bolt Turret Base* For Turret Cover Screw Plunger Spring Please ber
1 Dr. 1 Tu. 1 Pool
AT-461 AT-7202 or AT-7202-1 AT-6555 AT-9813 100206 AT-7208 6-9859 Give Model
10 W7100F

BE SURE WHEN ORDERING PARTS, GIVE MODEL NUMBER, PART NUMBER AND PART NAME. TO GIVE COMPLETE MODEL NUMBER WHICH IS STAMPED ON SIDE OF TURRET



HARDINGE BROTHERS, INC., ELMIRA, NEW YORK, U.S.A.

							i
							ŗ
,	e j					-	
		ų, s					
							j
							¢*
					-		